

OF CONTENTS

	<u>Page</u>
SECTION I	
1. DESCRIPTION	
.....	1-1
.....	1-1
n	1-1
.....	1-1
.....	1-3
.....	1-3
.....	1-3
.....	1-4
.....	1-4
SECTION II	
2. AND INITIAL ADJUSTMENT	
.....	2-1
.....	2-1
.....	2-1
.....	2-1
SECTION III	
3. OPERATION	
.....	3-0
.....	3-0
.....	3-0
.....	3-2
.....	3-2
SECTION IV	
4. MODE OF OPERATION	
.....	4-0
s	4-1
ls	4-1
s	4-1
ls	4-1
.....	4-1
its	4-1
.....	4-17
.....	4-19
.....	4-20
.....	4-22

TABLE OF CONTENTS (Cont.)

<u>Paragraph</u>		<u>Page</u>
SECTION V MAINTENANCE AND ALIGNMENT		
5.1.	Maintenance	5-1
5.1.1.	General	5-1
5.1.2.	Cleanliness	5-1
5.1.3.	Trouble Shooting	5-1
5.1.4.	Trouble Shooting Procedure	5-3
5.2.	Electrical Maintenance	5-6
5.2.1.	Test Conditions	5-6
5.2.2.	Exciter and Power Amplifier	5-7
5.2.3.	Alignment of KWS-1	5-8
5.3.	Mechanical Maintenance	5-13
5.3.1.	Dial Cord Replacement	5-13
SECTION VI PARTS LIST		
SECTION VII ILLUSTRATIONS		
SECTION VIII ANTENNAS WITH 52-OHM COAXIAL FEED LINES		
8.1.	General	8-1
8.2.	Antenna Details	8-1
8.3.	Transmission Line	8-2
8.4.	Test Information	8-2

ILLUSTRATIONS

	<u>Page</u>
.....	1-0
.....	1-2
.....	2-2
.....	2-2
.....	2-3
.....	3-1
.....	3-1
.....	4-0
.....	4-2
1 Filter, Simplified Schematic Diagram .	4-3
r, Simplified Schematic Diagram	4-4
e Pattern.	4-5
.....	4-5
oscope Pattern	4-6
n	4-7
tralization Circuits, Simplified Schematic	
.....	4-10
dge Diagram	4-11
its (80 Meters), Simplified Schematic	
.....	4-11
e Diagram (80 Meters)	4-12
its, (40, 20, 15, 11 and 10 Meters),	
.....	4-12
e Diagram (40, 20, 15, 11 and 10 Meters)	4-13
ation Circuits, Simplified	
.....	4-13
ation Bridge Diagram	4-14
ematic Diagram	4-15
n	4-16
.....	4-18
Adjustments	5-5
.....	5-14
.....	6-31
Open	6-32
View	6-33
Removed	6-34
.....	6-35
.....	6-36
uding Power Amplifier	6-37
.....	6-38
.....	6-39
.....	6-39
.....	6-40
Removed	6-41
rel Removed	6-42
Removed	6-43
.....	6-44
ed	6-45

LIST OF ILLUSTRATIONS (Cont.)

	<u>Page</u>
Amplifier, Complete Schematic Diagram	7-3/7-4
Complete Schematic Diagram	7-5/7-6
Table, Wiring Diagram	7-7
Assembly to Connectors	7-8
Assembly to Connectors	7-9
Open Wire Line for Reduction of Losses on Long Transmission Lines	8-3
With Shortened Unbalanced to Balanced Transformer (Balun) Feed System	8-4
With Shortened Unbalanced to Balanced Transformer (Balun) Feed System	8-5
With Quarter-Wave Unbalanced to Balanced Transformer (Balun)	8-6
With Quarter-Wave Unbalanced to Balanced Transformer (Balun)	8-7
and 80 Meters	8-8

LIST OF TABLES

	<u>Page</u>
uning and Loading Dial Settings	3-3
ponents	4-9
dings	4-22
.	5-7
.	5-7
ment	5-11
o Ground	5-15
es to Ground	5-16
erformance Specifications	8-1