

TABLE OF CONTENTS

<u>Paragraph</u>		<u>Page</u>
SECTION 1 - GENERAL DESCRIPTION		
1.1.	GENERAL	1-1
1.1.1.	Purpose of Book	1-1
1.1.2.	Purpose of Equipment	1-1
1.1.3.	Description	1-1
1.1.4.	Equipment Supplied	1-2
1.1.5.	Accessories Available	1-2
1.2.	VACUUM TUBE TABLE	1-3
1.3.	REFERENCE DATA	1-3
SECTION 2 - INSTALLATION		
2.1.	UNPACKING	2-0
2.1.1.	Procedure	2-0
2.2.	INSTALLATION	2-0
2.2.1.	General	2-0
2.2.2.	Antenna Connection	2-0
2.2.3.	Audio Output Connections	2-0
2.2.4.	I-F Output Connection	2-0
2.2.5.	Remote Standby Connections	2-0
2.2.6.	Power Connection	2-0
2.2.7.	Tubes.	2-0
2.2.8.	Fuse	2-2
SECTION 3 - ADJUSTMENT AND OPERATION		
3.1.	ADJUSTMENT	3-1
3.1.1.	General	3-1
3.2.	OPERATION	3-1
3.2.1.	Function of Controls	3-1
3.2.2.	Tuning AM Signals	3-3
3.2.3.	Tuning Single-Sideband Signals	3-4
3.2.4.	Tuning CW Signals	3-4
3.2.5.	Frequency Measuring	3-5
3.3.1.	General	3-5
SECTION 4 - CIRCUIT DESCRIPTION		
4.1.	MECHANICAL DESCRIPTION.	4-0

SECTION 4 - CIRCUIT DESCRIPTION (CONT.)

	<u>Page</u>
GENERAL DESCRIPTION	4-3
General	4-3
Radio Frequency Amplification	4-3
Mixer Stages	4-5
High Frequency Oscillator	4-5
Variable Intermediate Frequency	4-7
Variable Frequency Oscillator	4-7
Crystal Filter	4-7
Second Intermediate Frequency	4-9
Detector	4-9
Gain Limiter	4-9
Automatic Volume Control	4-11
Radio Amplifier	4-11
Ohm I-F Output	4-11
10 KC Calibrator	4-11
Power Supply	4-12
Beat Frequency Oscillator	4-12
Mechanical Filter	4-12

SECTION 5 - MAINTENANCE

INDEX	5-1
General	5-1
Routine Inspection	5-1
Cleaning	5-1
Vacuum Tubes	5-1
Tube Replacement Precautions	5-1
Tube Table	5-1
HOOTING	5-2
General	5-2
Tests	5-2
.	5-2
General	5-2
Equipment and Tools Used for Alignment	5-2
Crystal Oscillator Trimmer Adjustment	5-2
10 KC Oscillator Alignment	5-3
Fixed 500 KC I-F Amplifier Alignment	5-3
Alternate BFO Alignment Method	5-5
10 KC I-F Performance Measurements	5-5
Alignment of Dials with VFO	5-6
Variable I-F Alignment and RF Alignment Band 2	5-9
Variable I-F Alignment and RF Alignment Band 3	5-9
I-F Alignment Bands 4-7	5-10
I-F Alignment Bands 8-15	5-10
I-F Alignment Bands 16-30	5-10
I-F Alignment Band 1	5-10
VFO Alignment	5-10
Adjustment of L-124	5-12
Intermediate Amplifier Gain Adjustment	5-12

SECTION 5 - MAINTENANCE (CONT.)

	<u>Page</u>
REMOVAL AND REPLACEMENT	5-12
STATIC DISCHARGE BULB REPLACEMENT	5-13
b Replacement	5-13
Discharge Bulb	5-13
CHANGE GEAR MAINTENANCE	5-13
.	5-13
Assembly of Gear Box	5-13
Disassembly of Gear Box	5-15
ASSEMBLY MAINTENANCE	5-17
.	5-17
Adjustment of Cams	5-17
.	5-18
Adjustment of Pointer Cord	5-18
.	5-19

SECTION 6 - PARTS LIST

SECTION 7 - PARTS IDENTIFICATION AND SCHEMATIC

ISTRATIONS

	<u>Page</u>
am (C01-09-P)	1-0
.	2-1
.	2-1
Operation Relay Circuit C01-02-3.	2-2
.	3-2
(C) the 51J-4, Using the 3KC Mechanical	
.	3-3
k Diagram C01-03-4	4-1
4	4-2
401-4.	4-4
.	4-8
l" (A11-409-2).	4-8
-408-1)	4-9
.	4-10
.	4-10
.	5-4
.	5-8
.	5-9
14-4)	5-14
.	5-18
.	5-19
.	5-23
m (C01-12-P)	7-1
.	7-2
tors (C01-14-P)A	7-3
l (C01-15-P)B	7-4
j-P)	7-5
'-P)	7-6
6)	7-7